


TOCON starter kit *optional TOCON accessory*

Features



Properties of the TOCON starter kit

- Kit for initial testing setup – take a standard voltmeter from your toolbox and get into the world of UV radiometry.
- output voltage 0 9 V
- Usable with all TOCON detectors (not included)
- 9V block battery included, typical runtime 3000 hours
- Separate 4mm banana plug ground and signal cable for easy connection

How to connect

- Put a TOCON into the 3pin transistor socket.
- Connect the 9V battery.
- Put the 4mm banana plug connectors into your voltmeter
 - yellow = signal voltage out = plus terminal of the voltmeter
 - black = ground = ground terminal of the voltmeter